

Quick-Start Guide

KEYPAD TABLETOP ENCLOSURE

For Model: Keypad Tabletop Enclosure (#2402WH or 2402BK)

Your Keypad Tabletop Enclosure contains:

- Enclosure lid and base
- 2 enclosure screws
- 3 wire nuts
- Power cord
- Strain-relief grommet



Need Help? For assistance call your friendly support person @ 866-243-8018

Setting Up the Keypad Tabletop Enclosure

Step 1. Unpack enclosure and verify contents (see above).

Step 2. Install a wire nut on the red (or load) wire to prevent shorting or causing a shock.

Step 3. Remove the 2 screws already attached to your KeypadLinc; these will not be needed.

Step 4. Thread the stripped wire end of the power cord through the hole in the base of the enclosure so that 6-8 inches of the power cord wires are available from inside the enclosure.

Step 5. Locate the wires labeled "neutral" on both the power cord and KeypadLinc. Using a wire nut, connect these two wires together.

Step 6. Locate the wires labeled "line" on both the power cord and KeypadLinc. Using a wire nut, connect these two wires together.

Step 7. Install the KeypadLinc into the enclosure so that the wire nuts are tucked into the large end of the enclosure behind the KeypadLinc's mounting plate.

Step 8. Install the front cover (lid) of the enclosure, over the KeypadLinc, to the base of the enclosure. From the bottom of the enclosure, insert the enclosure screws through 2 screw holes and tighten into the front cover until the front cover is snug against the enclosure base.

Step 9. Plug the power cord into a convenient outlet (preferably unswitched).

Step 10. See <http://www.smarthome.com/manuals/2486dqs.pdf> "Setting up your Keypad Dimmer to control an INSTEON Device Remotely."

Step 11. Configuration and Operation – Please see the Quick-Start Guide for your KeypadLinc for instructions.

Congratulations! Your KeypadLinc is installed and ready for linking!