



## Stainless Steel Grill Light Model # GL-03

### INSTALLING / REPLACING BATTERIES:


1. Remove the battery door by opening the battery cover (see Fig. 1) and replace the old batteries with three (3) new 1.5V AA heavy-duty (carbon-zinc) batteries.
2. Make sure the batteries are oriented correctly on the positive & negative terminals.
3. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

### INSTALLING GRILL LIGHT:

1. Do not position the Grill Light above fire or any cooking surface.
2. If your grill has a side burner: You must mount the light on the side of your grill opposite the side burner.  
If your grill does not have a side burner: You may mount the light on either side of your grill.
3. The light has a gooseneck design which allows you to position the light wherever you desire.

### USE AND CARE:

1. Store Grill Light indoors when not in use.
2. Grill Light can be cleaned by gently wiping with a damp towel. DO NOT IMMERSE IN WATER.
3. Remove batteries if Grill Light is to be unused for two weeks or more, since batteries could leak and damage the grill Light.
4. Do not incinerate, compact, or disassemble batteries.
5. Recycle old batteries whenever possible. If recycling is unavailable in your area, dispose of old batteries in accordance with local regulations.
6. Turn ON or turn OFF the light by the switch in the front of the unit.



### Limited ninety day warranty

This Grill Light is warranted by Maverick Industries, Inc., to be free from defects in materials and workmanship for a period of ninety (90) days from date of purchase. In the event of any claim under this limited warranty, Maverick Industries, Inc., will repair or replace at its sole option any unit or part(s) thereof, provided such units or part(s) are sent freight prepaid to the Customer Service Department, Maverick Industries, Inc., Grill Light, 94 Mayfield Avenue, Edison, NJ 08837.

<http://www.maverickhousewares.com>