

Installation Guide for LED Elegant Placemats

To activate batteries remove plastic strip before usage.

Battery pouch is located on the right-side upper corner.

To turn lights on or off, press on/off button located at the top left hand corner. An on/off sticker will be placed over button.

