

IMPORTANT SAFETY INSTRUCTIONS

The Digital Innovations "Doctor Series" Motorized AutoMax Disc Repair System has been manufactured and tested with your safety in mind. Please read and observe all safety points outlined in this guide for operating your new product and save them for future reference. Observing these simple precautions can help you get many years of enjoyment and safe operation from your new product.

CARE GUIDELINES

- This product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.
- Do not use this product near water. This includes, but is not limited to sinks, tubs, basins, pools as well as wet floors.
- Use only exact replacement parts and accessories as specified by Digital Innovations, as using not recommended parts may cause irreparable damage to the unit and disc.
- When using the Power Adapter consider the following:
 - Always unplug product from electrical outlet before cleaning
 - Improper use can result in potential electrical shock or fire
 - This product should be operated only from a type of power source indicated on the label.
 - Power supply cords should be routed clear of foot traffic and any items that may put pressure on or cause pinching of the cord.
 - Pay close attention to portions of the cord nearest to the plug and product entry point.
 - To avoid possible damage by power surges, unplug unit from electrical outlet when not in use
 - Do not overload wall outlets and extension cords as this can result in electric shock or fire
 - Use only exact replacement parts and accessories as specified by Digital Innovations, as using not recommended parts may cause irreparable damage to the unit and disc.

SERVICE

- Do not attempt to service this product yourself. Contact Digital Innovations for any service-related questions.
- Contact Digital Innovations for service information if:
 - The product has been dropped or the housing has been damaged
 - The product exhibits a distinct change in performance
 - The product has been exposed to rain, water, or liquid
 - An object has fallen into the unit
 - The power supply cord or plug is damaged

SERVICE AND WARRANTY INFORMATION

LIFETIME WARRANTY

The Digital Innovations "Doctor Series" Motorized AutoMax Disc Repair System is warrantied for life. If your device fails to perform to specifications for any reason, simply return your device directly to Digital Innovations, and we will repair or replace your unit at no cost. This warranty does not apply to resurfacing wheels, resurfacing fluid, fluid bottles, drying cloths, or felt buffing squares. Some restrictions apply outside the United States.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OF FITNESS FOR A PARTICULAR PURPOSE, AND NO PERSON OR REPRESENTATIVE IS AUTHORIZED TO ASSUME FOR THE COMPANY ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THIS PRODUCT.

THIS WARRANTY EXCLUDES INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OF THIS PRODUCT.

Some states in the U.S. do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. This warranty gives you specific legal rights and you may also be entitled to other legal rights required by your state.

For more information on any or all of these tips, as well as troubleshooting suggestions and Frequently Asked Questions, visit our website,

www.digitalinnovations.com

Patents #5,423,103 and #5,964,650

Other Patents Pending Worldwide

Digital Innovations, LLC • Arlington Heights, IL • Email: sales@digitalinnovations.com


Phone (Customer Support) 1-888-SMART-58 (Hours: 8:30 AM to 4:00 PM, CST Monday-Friday)

Register online at **www.digitalinnovations.com**

©2005 Digital Innovations, L.L.C. All Rights Reserved

Printed in China

Form# LA059A1



**FIXES
SCRATCHED
DISCS**

skipDR. dvdDR. gameDR. EXCELERATOR

**MOTORIZED
AUTOMAX
DISC REPAIR SYSTEM**

USER'S GUIDE



INTRODUCTION


Congratulations! You've just purchased the world's leading disc repair solution. Digital Innovation's "Doctor Series" Motorized AutoMax Disc Repair System uses motorized, patented radial wheel technology to automatically fix most scratched optical discs including music CDs, DVDs, game discs, photo discs and data CD-ROMs. Your "Doctor Series" Motorized Automax Disc Repair System will help your discs to maintain their optimal play condition for years to come!

KEY FEATURES AND BENEFITS

- Safe and effective patented design fixes virtually any type of scratched disc
- Easy to use, motorized operation
- Automatic power-on, disc-resurfacing and disc-ejection feature
- Convenient desktop design
- Repair-function LED
- Integrated cloth and bottle storage
- Lifetime warranty
- 2 convenient power options: battery-operated (requires 6 AA batteries, not included) or DC power adapter (sold separately)

REPAIR SYSTEM INCLUDES:

- 1- Resurfacing Unit
- 1- Resurfacing Wheel
- 1- Disc Resurfacing Fluid Bottle
- 1- Drying Cloth
- 1- Felt Buffing Square
- 1- User's Guide



Please be sure to register your new device on-line at www.digitalinnovations.com

Note: To ensure optimal repair for your damaged discs, please read all instructions thoroughly!

GETTING STARTED

1. Open battery door on bottom of unit and insert 6 AA batteries (alkaline recommended). If using optional DC power adapter (sold separately), plug transformer into electrical outlet. Plug jack into unit base.



2. Generously spray entire play-side of damaged disc (the side opposite disc label), using provided Resurfacing Fluid. Resurfacing Fluid is completely safe and environmentally-friendly.



3. Gently insert disc completely into Repair System's disc slot with play-side of disc facing Resurfacing Wheel. Device will power-on automatically and begin repair process.



4. Disc will rotate inside device for about 1 minute. When repair process is complete, unit will automatically eject disc. Remove disc from device and dry off any excess moisture using provided drying cloth.



5. IMPORTANT!!! Place disc (play-side up) on protected flat surface. Using Felt Buffing Square, buff resurfaced, dry disc thoroughly. Buffing restores the disc's shiny appearance, and ensures optimal disc performance. Scratches do not have to be removed completely for the disc to play perfectly.



6. When not in use, the Drying Cloth, Felt Buffing Square and Resurfacing Fluid Bottle can be stored conveniently in unit as shown.



Note: The "Doctor Series" Motorized AutoMax Disc Repair System will not repair severe damage such as gouges and deep scratches, label side damage and warping.

TIPS

Your "Doctor Series" Motorized AutoMax Disc Repair System is proven to repair the primary causes of skipping and distortion in music, movie, photo, data and game discs.

We have put together the following helpful hints and tips to ensure the optimal results to your disc repair. ***If after following and reviewing this information, you are not completely satisfied, please visit our website for a demonstration OR call us at 1-888-SMART-58, between 8:30 am and 4:00 pm CST Monday through Friday.*** We want to hear from you!

- The final buffing step will help prevent new problems and ensures best repair results. You can buff as hard as you want, as it will not harm the disc. Store buffing square as recommended to keep it clean and free from debris which could cause scratches. Replacement felt is available from your local retailer or directly from Digital Innovations.
- A disc's play-side is usually the "shiny" side and the label side is the "dull" side.
- To remove and replace a Resurfacing Wheel:
 - If a disc is in the Disc Slot, remove it.
 - Gently pull the existing Resurfacing Wheel from the Resurfacing Unit. To do this, pull wheel away from wheel hub with fingers and remove.
 - Insert new Resurfacing Wheel, ensuring that protruding center of wheel is facing inward. Rotate wheel to align hub and wheel and press firmly to seat.
- If the disc is not completely repaired on the first try, repeat until completely fixed or no further improvement is evident. If the disc still skips, your disc player may need cleaning, repair, or disc scratch may be too deep. Also, examine disc for label-side damage. Test with a disc that you know is not damaged.
- Discs with label side damage cannot be repaired by any method. To identify label side damage:
 - Scratches visible on the label side of a disc are always due to label-side damage, but the reverse is not always true. Label side-damage can look like play-side damage when viewed straight-on from the play-side. Here's how to check:
 - Method #1- Hold the disc a foot or so from a light source with the play (shiny) side facing you. If you can see through a scratch, that scratch is definitely on the label side. If you can't see through the scratch, it is probably on the play-side. Use Method #2 to be sure.
 - Method #2- Tilt disc so you are looking at the scratch from an angle. If the scratch has a reflection in the surface of the disc then the scratch is on the play-side. If not, the scratch is on the label side.
- Circumferential scratches (curved scratches that lie in a direction around the disc) are more likely to cause problems than radial scratches (that run from inside center to outside rim of disc).
- Store the "Doctor Series" Motorized AutoMax Disc Repair System in a dust-free environment at room temperature. If it is stored in a warmer or cooler temperature, allow it to return to room temperature before using.
- It is very important to keep discs wet during the resurfacing process, or discs may become damaged.
- To maximize resurfacing life, rinse wheel under cold water after each use. Do not let soak for long periods of time.
- The same disc can be repaired multiple times.
- If the units batteries are drained such that the disc does not complete a full cycle before it is ejected, replace the batteries.
- If attempting to repair 30 or more discs at one time, a DC power adapter (optional) is recommended.