

# **WR-100 EXTRA-LOUD TELEPHONE RINGER**

## **CONNECTING THE WR-100 TELEPHONE RINGER**

1. Insert one end of the flat telephone cord, provided with your system, into either one of the jacks located on the top end of the telephone ringer. **NOTE:** It does not matter which jack on the WR-100 you use.
2. Insert the opposite end of the cord into the wall jack.
3. If you want to have a phone connected to the same jack where you are connecting your WR-100, then simply plug the telephone into the extra jack on the top end of the WR-100. **NOTE:** A telephone does not have to be hooked up to the WR-100.

## **OPERATION**

1. The volume level is controlled with the slide control conveniently located on the front side of the WR-100 case.
2. Slide the volume control to the right to increase the volume; slide to the left to decrease the volume.
3. The slide control located on the side of the unit adjusts the tone of the ringer. Sliding the control all the way to the left produces the lowest tone. It is recommended that those with high frequency hearing loss set the tone to the lowest setting. Sliding the control to the right, or high, produces a very high frequency ring tone.
4. The red visual ringer indicator located in the upper right-hand corner will automatically light up to alert the user of an incoming call.
5. The on/off switch can be used to disable the ringer. If the switch is turned to the off setting, the visual indicator will still illuminate.

## **MAINTENANCE**

The WR-100 telephone ringer may be cleaned when necessary with a mild detergent. Use a damp (not wet) cloth. Never use abrasives or solvents. This ringer is designed for long service and dependable operation. If any problem occurs, disconnect the unit and contact a Walker Customer Service Representative at 1-800-552-3368.

## WARRANTY & SERVICE

The following warranty and service information applies only to products purchased and used in the U.S. and Canada. For warranty information in other countries, please contact your local retailer or distributor.

### Limited Warranty

Walker, a division of Plantronics, Inc. ("Walker") warrants to the original consumer purchaser that, except for limitations and exclusions set forth below, this product shall be free from defects in materials and workmanship for a period of two (2) years from the date of original purchase ("Warranty Period"). The obligation of Walker under this warranty shall be limited to repair or replacement, at Walker's option, without charge, of any part or unit that proves to be defective in material or workmanship during the Warranty Period.

### Exclusions from Warranty

This warranty applies only to defects in factory materials and factory workmanship. Any condition caused by accident, abuse, misuse or improper operation, violation of instructions furnished by Walker, destruction or alteration, improper electrical voltages or currents, or repair or maintenance attempted by anyone other than Walker or an authorized service center, is not a defect covered by this warranty. Telephone companies manufacture different types of equipment and Walker does not warrant that its equipment is compatible with the equipment of a particular phone company.

### Implied Warranties

Under state law, you may be entitled to the benefit of certain implied warranties. These implied warranties will continue in force only during the warranty period. Some states do allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

### Incidental or Consequential Damages

Neither Walker nor your retail dealer or selling distributors has any responsibility for any incidental or consequential damages including without limitation, commercial loss or profit, or for any incidental expenses, expenses, loss of time, or inconvenience. Some states do not allow exclusion or limitation of incidental or consequential damage, so the above limitation or exclusion may not apply to you.

### Other Legal Rights

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

### How to Obtain Warranty Service

To obtain warranty service, please prepay shipment and return the unit to the appropriate facility listed below.

#### In the United States:

Walker Service Center  
4289 Bonny Oaks Drive, Suite 106  
Chattanooga, Tennessee 37406  
Tel. (423) 622-7793 or  
(800) 426-3738  
Fax: (423) 622-7646 or  
(800) 325-8871

#### In Canada:

Plantronics Service Center  
1455 Pitfield Boulevard  
Saint-Laurent  
Quebec H4S 1G3  
Tel: (800) 540-8363  
(514) 956-8363  
Fax: (514) 956-1825

Please use the original container, or pack the unit(s) in a sturdy carton with sufficient packing material to prevent damage. Include the following information:

1. A proof-of-purchase indicating model number and date of purchase.
2. Bill-to address
3. Ship-to address
4. Number and description of units shipped
5. Name and telephone number of person to call, should contact be necessary
6. Reason for return and description of the problem. Damage occurring during shipment is deemed the responsibility of the carrier, and claims should be made directly with the carrier.